



**NOTE:**

1. REFER TO THE MECHANICALLY PURLIN ATTACHMENT TABLE FOR ADDITIONAL INFORMATION.
2. USE STRIPPING DETAIL APPROPRIATE TO THE MEMBRANE, METAL TYPE AND GUARANTEE PERIOD. REFER TO EVERGUARD® 200 SERIES DETAILS.
3. CLEAN METAL AND MEMBRANE WITH EVERGUARD® TPO SEAM CLEANER AND ALLOW TO DRY. ONCE DRY, PRIME METAL AND MEMBRANE WITH EVERGUARD® TPO PRIMER BEFORE INSTALLING EVERGUARD® TPO COVER TAPE.



**METAL ROOF EDGE DETAIL  
- PURLIN ATTACHEMNT**

DRAWING #  
**202F**

THIS DETAIL APPLIES TO:  
RHINOBOND® SYSTEMS  
MECHANICALLY ATTACHED SYSTEMS

ISSUE / REVISION DATE  
**8/17/20**

SCALE  
N.T.S.

**LEGEND**

- HEAT-WELDED LAP
- PEEL-N-STICK ADHESIVE  
(SEE NOTE #3)