



NOTE:

1. REFER TO THE MECHANICALLY PURLIN ATTACHMENT TABLE FOR ADDITIONAL INFORMATION.
2. USE STRIPPING DETAIL APPROPRIATE TO THE MEMBRANE, METAL TYPE AND GUARANTEE PERIOD. REFER TO EVERGUARD® 200 SERIES DETAILS.
3. REMOVE EXISTING FLOATING RAKE AND CLIP.
4. CLEAN METAL AND MEMBRANE WITH EVERGUARD® TPO SEAM CLEANER AND ALLOW TO DRY. ONCE DRY, PRIME METAL AND MEMBRANE WITH EVERGUARD® TPO PRIMER BEFORE INSTALLING EVERGUARD® TPO COVER TAPE.



**METAL ROOF EDGE DETAIL
- FLOATING RAKE EDGE**

DRAWING #
2021

THIS DETAIL APPLIES TO:
RHINOBOND® SYSTEMS
MECHANICALLY ATTACHED SYSTEMS

ISSUE / REVISION DATE
8/17/20

SCALE
N.T.S.

LEGEND

- HEAT-WELDED LAP
- PEEL-N-STICK ADHESIVE (SEE NOTE #3)