



NOTE:

1. DRILL-TEC™ FASTENERS AND RHINOBOND® PLATES MUST BE INSTALLED A MAXIMUM 6" (152 mm) FROM THE ANGLE CHANGE.
2. REFER TO THE DRILL-TEC™ RHINOBOND® ATTACHMENT TABLES FOR DETAILED INSTALLATION REQUIREMENTS REGARDING DECK TYPE, PLATE & FASTENER TYPE, AND MIN. EMBEDMENT.
3. EVERGUARD® BONDING ADHESIVE OPTIONAL UP TO 30" (762 mm) FLASHING HEIGHT.



BASE TIE-IN CONTINUOUS FLASHING AT ANGLE CHANGE

DRAWING #
307B

THIS DETAIL APPLIES TO:
RHINOBOND® SYSTEMS

ISSUE / REVISION DATE
8/11/20

SCALE
N.T.S.

LEGEND

- EVERGUARD® BONDING ADHESIVE
- INDUCTION HEAT-WELD