




Instructions:

Open the Layers tool palette in a compatible PDF viewer such as Adobe Acrobat or Bluebeam Revu. Disable the "Instructions" layer to remove this note, and enable the layer with the desired number of fasteners. You can also enable the appropriate layer for roof area to indicate "Corner", "Perimeter", or "Field" within the drawing title block.



Notes:

1. Refer to the system manual for deck and fastener requirements.
2. Not applicable for induction welded systems. Refer to induction welded details for fastener placement.
3. Fastener placement is shown in accordance with FM Global data sheet 1-29, appendix C.

Visit GAF.com for requirements and instructions on using interactive details.

**2' x 4' Roof Board
Fastening Pattern**

Roof Area:

Detail No:

Issue Date:
5/4/23

Scale:
3/4" = 1'