



NOTE:

1. ATTACH WOOD BLOCKING TO DECK OR STRUCTURAL STEEL ANGLE SUPPORTS AS APPROPRIATE.
2. SECURE METAL COVERPLATE AT TOP EDGE OF CURB WITH SELF-SEALING SCREW FASTENERS.
3. ALL MEMBRANE BASE FLASHINGS MUST BE PROTECTED FROM DAMAGE BY MEANS OF METAL (MINIMUM 24 GAUGE COPPER OR 0.032" ALUMINUM) COUNTERFLASHING EXTENSIONS THAT PROVIDE 100% COVERAGE OF THE BASE FLASHINGS TO BELOW THE TOP OF THE TRAFFIC SURFACING.



GAFGLAS
Built-Up Roofing Systems
RUBEROID
Modified Bitumen Roofing Systems

**CURB-TYPE EXPANSION JOINT
FLASHING DETAIL**

DRAWING #

401

SYSTEM

PD

WWW.GAF.COM
1 Campus Drive.
Parsippany, NJ
07054

SCALE

N.T.S.

ISSUE/ REVISION DATE

9-20-15